












PART LIST TV303

1	2	3	4
	 x 2	 x 1	 x 1
	5	6	7
 x 1	 x 1	 x 1	 x 1
P1	P2	P3	S1
 x 1	 x 1	 x 1	 GT-22 F x 20

ADULT ASSEMBLY REQUIRED

ASSEMBLING INSTRUCTION TV303



ADULT ASSEMBLY REQUIRED